



B = h = Aussenmass

T = Wandstärke

Code	B	h	T	Gewicht	Toleranzen und Bemerkungen
	mm	mm	mm	kg/m	
7001	20	20	1,5	300	SP.1,5 +0,15/-0,05
7002	20	20	2	389	
7004	25	25	1,5	381	
7005	25	25	2	497	
7008	30	30	1,5	462	
7010	30	30	2	605	R2
7012	30	30	2	605	
7013	30	30	2	605	R 1,5
7014	30	30	3	875	
7011	30	30	4	1123	
7015	35	35	2	713	
7021	40	40	1,5	624	
7022	40	40	2	821	
7023	40	40	2,5	1013	
7027	40	40	3	1199	
7026	40	40	4	1555	
7024	45	45	1,5	705	
7025	45	45	2	929	
7030	50	50	1,5	786	
7032	50	50	2	1037	
7033	50	50	3	1523	
7034	50	50	4	1987	
7040	60	60	2	1253	
7041	60	60	3	1847	
7050	70	70	2	1469	
7052	70	70	3	2171	
7053	70	70	4	2851	
7063	80	80	2	1685	